KitchenAid®

CABINET PARTS

For Model: KSSS42DBW00

REFRIGERATOR



1		Cabinet (Not A Serviceable Part)
2	1112019	Leveler, Front (2)
3	1113249	Retainer (2)
4	1112023	Roller, Front & Rear (4)
5	1112695	Leveler, Adjustable (2)
6	2000670	Adjusting Rod (2)
7	1113250	Sleeve, Retainer (2)
8	1112937	Bushing, Rod (2)
9	489359	Screw
10	1112939	Hole Plug, Leveler
11	1112849	Cap, Grommet
12	1112970	Grommet, Water Tube
13	1113122	Grommet, Wiring
14	2001999	Wiring Harness, Cabinet
15	1112848	Drain Fitting
16		Gap, Cover Assembly (Top)
	2000305	Left Side
	2000304	Right Side
17	2001295	Shoulder Screw
18		Hinge (Top)
	2000306	Left Side
	2000307	Right Side
19	2000770	Shim, Hinge Top
20	1112805	Guard, Wiring
21	487534	Screw (2)
23	1112992	Door Closer Assembly (2)
24	2000333	Bracket, Door Closer
25	486194	Screw
26	1112973	Tap Plate, Hinge Butt (2)
27	1113227	Fastener (3)
28		Gap, Cover Assembly (Bottom)
	2001200	Left Side
	2001199	Right Side
29		Hinge (Bottom)
	2001733	Left Side
	2001732	Right Side
30	1112942	Shim, Hinge (1)
	1112943	Shim, Hinge (2) Bottom (4)
31	2000490	Screw,
33	2001266	Tube clamp
34	2001960	Grille Base, Front
35	489238	Screw (6)
36	2000684	Cover, Rear
37	1113123	Grommet, Wiring
38	1113079	Grommet, Flexible
39	1112926	Grommet, Tube
41	2001377	Screw
42	2000530	Grommet
43	2001415	Screw (8)
44	489359	Screw

CABINET TRIM PARTS

For Model: KSSS42DBW00



1	2001390	Cabinet, Trim R.S
2	2001391	Cabinet, Trim L.S
3	2001297	Screw
4	2001189	Cabinet, Trim (Bottom)
5	488649	Screw
6	2001388	Cabinet, Trim Top
7	2000007	Retainer, Unit Base (2)
8	487944	Washer (2)

TOP GRILLE AND UNIT COVER PARTS

For Model: KSSS42DBW00



1	2002675	Top Grille Assembly
2	2001313	Decorative Panel Assembly
3	1113355	Back Up Panel
4	2001883	Cover, Unit
5	486194	Screw
6	2001874	Cover, Component Assembly
7	1113317	Brace

REFRIGERATOR LINER PARTS

For Model: KSSS42DBW00



1		LINER (Not A Serviceable Part)
2	1112591	Spacer, Control Panel (3)
3	502037	Grommet, Screw
5	2001117	Ladder, Shelf (2)
6	520965	Screw Support, Ladder (8)
7	488357	Screw (8)
8	486194	Screw
9	1112257	Hole Plug
10	2000740	Meat Pan, Air Duct Cover (Also Order 12)
11	2000337	Meat Pan, Air Duct
12	2001302	Inlay, Control Meat Pan
13	2001326	Seal, Air Duct
14	1112218	Damper Control, Meat Pan
15	2001735	Control Knob, Meat Pan
16	837444	Retainer, Knob
17	2000343	Air Baffle Assembly
20	2001073	Wiring Harness, Air Baffle
21	2001146	Seal
22	1116793	Cover, Thermistor
23	1116959	Thermistor
25	2000736	Air Baffle Cover
26	2000527	Guard, Air Return

FREEZER LINER PARTS

For Model: KSSS42DBW00



1		Liner (Not A Serviceable Part)
6	538533	Support Clip, Icemaker (2)
7	2000193	Grommet, Screw (2)
8	488552	Screw (2)
9	992720	Stud, Support (4)
12	486194	Screw
13	1112591	Spacer, Control Panel (3)
14	842534	Clip, Air Duct (4)
16	1112260	Support, Evaporator
17	658944	Stud, Shelf (20)
18	487559	Screw (20)

ICE CONTAINER PARTS

For Model: KSSS42DBW00



1		Spacer, Track
	1112282	Left Side
	1112281	Right Side
2	1113870	Roller
3	1113871	Eyelet, Roller
5	1113169	Stop, Roller
6	488307	Washer
7	486194	Screw
8	1113126	Bracket, Motor
9	2155262	Motor Assembly
10	489399	Screw
11	983663	Coupling, Motor
12	1112613	Socket, Light
13	1113129	Cover, Motor
14	487294	Screw
15	1112286	Ice Container
16	1112378	Conveyor
17	983668	Coupling, Conveyor
18	946192	Drive Bar, Drum
19	946195	Bearing Nut
20	946193	Drum
21	946194	Baffle
22	2001034	Overlay, Cover
23	1112381	Front Cover
24	488886	Screw (5)
25	489211	Screw
28	1113140	Lens, Dispenser
29	547225	Light Bulb

REFRIGERATOR CONTROL PANEL PARTS

For Model: KSSS42DBW00



1	1112641	Control Panel
2	2000975	Inlay, Control Panel
3	2000789	Circuit Board
4	2001738	Control Knob
5	837444	Retainer, Knob
6	1108112	Switch, Rocker Arm
7	1113135	Seal, Control Panel
8	489260	Screw (3)
9	2000153	Hole Plug (3)
10	1113774	Shield, Control Panel
11	1112613	Socket, Light (2)
12	547225	Light Bulb (2)
13	486194	Screw
14	2001074	Control Harness
15	2001141	Channel, Wiring
16	1115375	Clip, Wiring (2)

FREEZER CONTROL PANEL PARTS

For Model: KSSS42DBW00



1	1112596	Control Panel
2	1113964	Inlay, Control Panel
3	1113466	Thermostat & Barrier Assembly
4	488974	Screw (2)
5	851387	Switch, Rocker Arm (Dispenser Motor)
6	1113134	Seal, Control Panel
8	489260	Screw (3)
9	2000153	Hole Plug (3)
10	1113768	Shield, Control Panel
11	1112613	Socket, Light
12	486194	Screw
13	547225	Light Bulb
14	1112707	Channel, Wiring
15	1108112	Switch, Rocker Arm (Light)
16	2001737	Knob, Thermostat
17	1115375	Clip, Wiring

REFRIGERATOR SHELF PARTS

For Model: KSSS42DBW00



1	1113543	Frame, Shelf
2	1112318	Glass, Shelf
3	1113547	Reflector, Shelf
4	1113791	Gasket, Glass (2)
5	1125913	Rack, Wine
6	2002181	Retainer, Glass
7	1113551	Frame Assembly
9	1113894	Cover, Crisper
10	2002147	Glass, Crisper
11	2164372	Egg Bin
12	2164373	Egg Carrier
13	2164374	Cover
14	2000888	Crisper Pan
15	1113870	Roller
16	1113871	Eyelet, Roller
17	489211	Screw
18	488307	Washer
19	2000892	Utility Pan
20	2000816	Meat Pan
21	2000742	Meat Pan Connector
25	1112165	Crisper Spacer, Right Side (2)
27	1113169	Stop, Roller
28	2002180	Crisper Spacer, Left Side (2)
29	486194	Screw

FREEZER SHELF PARTS

For Model: KSSS42DBW00



1	1112366	Solid Shelf
2	2000886	Front, Ice Compartment
3	1113565	Shelf, Bottom (2)
	1113637	Shelf, Top (1)
4	2001625	Basket
5	1113643	Trim, Basket
6	1113870	Roller
7	1113871	Eyelet, Roller
8	489211	Screw
9	488307	Washer
10	2000061	Slide, Basket R.S.
	2000062	Slide, Basket L.S.
11	1113169	Stop, Roller
12	486194	Screw

REFRIGERATOR DOOR PARTS

For Model: KSSS42DBW00



1	2000694	Door Panel, Refrigerator (Also Order Item 29)
2	939101	Screw Anchor (8)
3	2000696	Hinge Assembly, Top
4	2000303	Spacer, Top
5	489282	Screw
6	2000698	Hinge Assembly, Bottom
7	1112533	Gasket Retainer, Side (2)
8	1112541	Gasket Retainer, Top & Bottom
9	2000880	Door Gasket, Magnetic
10	489101	Screw (36)
11	2000388	Handle, Door
12	2002314	Tap Plate
13	2000697	Spacer, Bottom
15	2001208	Screw
16	2001398	Trim (Top)
17	2001209	Screw
18	2000391	Trim (Side)
19	2001402	Trim (Bottom)
20	1113953	Panel, Interior Door
21	1113951	Ladder, Shelf (2)
22	1112530	Retainer, Shelf Ladder (2)
23	1112514	Back Up Plate (8)
24	486194	Screw
25	1112721	Bin, Utility
26	1112736	Door, Utility Bin
27	2000912	Door Shelf (4)
28	1125936	Butter Tray
29	876029	Kit, Foam Slab (Required When Replacing Exterior Door Panel)
30	2001230	Washer

FREEZER DOOR PARTS

For Model: KSSS42DBW00



1	2001137	Exterior Door Panel, Freezer (Includes Insulation)
2	1112997	Tube, Wiring
3	1112928	Retainer, Tube
4	2002314	Tap Plate
6	2000720	Hinge, Bottom
7	489282	Screw
8	2000721	Hinge, Top
9	2001396	Spacer Plate
10	2001395	Spacer, Bottom
11	2001323	Wiring Harness, Freezer Door
12	1112533	Gasket Retainer, Side (2)
13	1112540	Gasket Retainer, Top & Bottom
14	2000879	Door Gasket, Magnetic
15	489101	Screw (34)
16	2000389	Handle, Door
17	2001230	Washer
20	2001208	Screw
21	2001407	Trim (Top)
22	2001209	Screw
23	2001410	Trim (Bottom)
24	2000390	Trim (Side)
26	1113946	Panel, Interior Door
28	2000605	Door Shelf,
32	227991	Wire Connector
33	939101	Screw Anchor
34	2000798	Ice Chute

DISPENSER AND FRONT PARTS

For Model: KSSS42DBW00



1	1124715	Housing, Dispenser
2	987049	Bracket, Water Fitting
3	2155020	Water Fitting Assembly (Includes Water Tube
4	487916	Screw
5		Water Tube (See Item #3)
9	488316	Screw
10	987048	Grommet
11	2001334	Heater, Ice Dispenser
12	2147167	Ice Door Mechanism
15	2147168	Ice Door
16	489000	Screw
17	2155815	Lever, Ice Dispenser
18	1129333	Shroud, Control
19	987917	Bearing, Clip
20	2159199	Lever, Water Dispenser
21	488307	Washer
22	983696	Spring, Lever
23	983697	Bearing, Lever
24	1120581	Delay Mechanism
25	1107454	Bracket, Control
26	841336	Switch
27	984683	Insulation, Switch
28	488361	Screw
29	987265	Lamp Holder
30	488500	Screw
31	851386	Light Switch
32	1107457	Plunger, Extension
33	983986	Spring, Plunger
34	983987	Retainer, Pin
35	2001350	Wiring Harness, Door
36	984494	Wiring Shield
37	2147479	Guide, Ice
38	2147480	Glass Stop
39	488892	Screw
40	487052	Screw
41	851389	Light Bulb
42	2001414	Front Cover, Housing Assembly (Includes Item 49)
44	1112836	Cover, Dispenser Opening
45	2001160	Trim, Front (2)
46	487052	Screw
47	1126120	Grille, Overflow
48	934316	Switch
49	2001176	Overlay, Cover
53	487944	Washer (2)
54	488568	Screw (2)
55	482672	Seal

UPPER UNIT PARTS

For Model: KSSS42DBW00



1	2001929	Assembly, Unit Base
2	2163787	Clip, Compressor Mounting (4)
3	2154558	Compressor (Includes Items 7, 8, 9, 10, 11 & 12) (Also Order)
	876765	Tube Kit
4	680975	Washer
6	2163786	Grommet, Mounting
7	1127675	Wire Assembly
8	2154761	Overload (Includes Relay)
9	1108115	Terminal Cover
10	938384	Strap, Cover
11		Relay (See Overload)
12		Capacitor
	2169137	Production
	2154565	Service
14	486899	Screw
15	487869	Screw
16	1113015	Condenser
17	943447	Grommet (4)
18	1113019	Clamp (4)
19	487522	Screw
20	1113228	Wire Tie (2)
21	1108023	Drier
22	2000358	Mounting Bracket, Motor
23	2002409	Motor, Fan
24	2000352	Blade, Fan
25	2000351	Orifice, Fan
26	1113303	Gasket, Orifice
27	489399	Screw (3)
28	489368	Screw
29	486692	Speed Nut
30	2162044	Defrost Timer
31	488911	Screw
32	2000645	Sleeve, Condenser
33	1113066	Clamp, Tube (2)
34	1113059	Process, Tube
35	486194	Screw
36	2000853	Cover, Fan
37	2001878	Cover, Condenser
38	1113076	Extension, Housing
39	937360	Service Cord
40	2001503	Seal Strip (2)
41	1113162	Clamp, Cord (2)
42	1113229	Switch, Power Disconnect
43	488879	Screw, Ground
44	653035	Clip, Cord Plug
45	2001078	Wiring Harness, Unit Compartment
47	2001079	Gasket (2)

Following Parts Not Illustrated and Optional Parts Not Included

978025	Valve, Access (1/4")
978026	Valve, Access (5/16")
978027	Valve, Access (3/8")
978028	Valve, Access (1/2")
978029	Valve, Access (5/8")
978030	Valve, Access (3/4")
876764	Valve, Access (3/16")

Refrigerant Charge 9.5 oz.

Production Compressor Requires Production Electrical Components. Service Compressor Requires Service Electrical Components. For Further Information, Refer to Filmcard 19.1.

LOWER UNIT AND TUBE PARTS

For Model: KSSS42DBW00



1	2000528	Defrost Bi-Metal
2	1113043	Clamp, Bi-Metal
3	486194	Screw
4	2002186	Sleeve
5	2002171	Sleeve
6	2002184	Condenser Inlet Tube
8	2002408	Tube, Connect (Drier)
9	2000755	Heater, Drain Pan
10	1113062	Hanger, Heater
11	1113105	Bracket, Heater
12	487534	Screw
13	2002381	Tube, Discharge
14	2002187	Sleeve
15	2001814	Heat Exchanger
16	2001132	Evaporator
17	2000631	Heater, Defrost
18	1113048	Clamp, Heater (2)
19	1108431	Clamp, Heater (2)
20	1112844	Gasket, Evaporator
21	857547	Wire Tie
22	1113070	Guard, Hook-Up
23	851095	Strap (7)
24	488946	Clamp, Wiring
25	2001264	Drain Pan
26		Bracket, Drain Pan
	1113206	(L.H.)
	1113207	(R.H.)
27	513942	Dampener
28	934011	Clip, Water Tube

AIR FLOW AND RESERVOIR PARTS

For Model: KSSS42DBW00



1	2001086	Fan Motor
2	488908	Screw
3	2169142	Fan Blade
4	548263	Bracket (Double)
5	938224	Bracket (Single)
6	548268	Grommet
7	486194	Screw
8	2000618	Motor, Wiring
9	488366	Clamp
11	489348	Clamp, Nylon
12	2001257	Channel, Wiring
13	2150347	Union
14	2000783	Scroll, Fan
16	488772	Screw
17	2000745	Assembly, Air Duct
18	2000048	Air Deflector, Icemaker
19	1112870	Cup, Motor
21	1112871	Fastener (3)
22	1112869	Gasket, Air Baffle
23	1113942	Cover, Air Outlet
25	2000341	Cover, Evaporator
26	2000795	Connector, Meat Pan Duct
27	487539	Screw
28	1112840	Baffle, Evaporator
29	1112852	Diffuser, Air Duct
30	2000861	Reservior, Water
31	488280	Screw
32		Evaporator, Cover Rail
	2000686	Left Side
	2000685	Right Side
33	2001337	Gasket (2) Evaporator Cover
34	2001079	Gasket (2)
35	2001080	Gasket
36	2001081	Gasket

ICEMAKER PARTS

For Model: KSSS42DBW00



1	489084	Screw
2	2000829	Fitting, Water Tube
3	2001087	Clamp, Tube
4	841707	Insert, Tube
5	628379	Clip, Fuse
6	2000392	Wire Clip
7	2001260	Tube, Water (To Ice Maker)
8	1106508	Seal Gasket
9	487627	Sleeve, Nut
10	2002182	Valve, Solenoid
11	627018	Nut, Compression
12	227991	Connector, Wire
13	2000836	Water Valve, Harness
14	2001354	Copper, Water Line
15	489348	Clamp, Nylon Valve
16	1113066	Clamp Tube
17	487857	Nut
18	628355	Cover
19	488645	Screw
20	628228	Mold & Heater (Also Order)
	542638	Silicone Grease
21	628258	Motor
22	628356	Cup-Water Fill
23	627843	Ejector
24	627788	Ice Striper
25	627790	Support
26	627796	Retainer Thermostat (2)
27	627985	Thermostat (Also Order)
	542639	Cement Alumilastic
28	489322	Screw
29	628357	Module Assembly
30	489276	Screw
31	2171593	Shut Off Arm
32	2002006	Harness, Wiring
33	627915	Bracket
34	489242	Screw
35	628366	Module Assembly (Includes Items 21, 29, 41)
36	2001098	Water Inlet Tube
37	2000803	Water Valve Mounting Bracket
41	489136	Screw (2)
42	488645	Screw
43	486194	Screw
44	1129179	Compression Nut
45	1129177	Insert, Tube
100	4317943	Icemaker

PARTS NOT ILLUSTRATED

Following Parts Not Illustrated (Optional Parts Only)

4210570	Front Panel Kit (White)
4210569	Front Panel Kit (Black)
4211160	Front Panel Kit (Almond)
4210594	Front Panel Kit (Stainless Steel)
978849	Black Acrylic Static Cleaner

LITERATURE PARTS

LIT2002424	Use & Care Guide

LIT2002435	Energy Label
LIT2002160	Service & Wiring Sheet
LIT628370	Modular Icemaker Service Sheet
LIT2002469	Installation Instructions